

DIGITAL PIANO KDP110 Operation Guide

KAWAI

SOUND

SOUND SELECT



Dual		Damper Resonance <small>(For Concert Grand, Studio Grand, Mellow Grand, Modern Piano only)</small>						Reverb			Touch			Brilliance <small>(-10--+10)</small>			Virtual Technician			Spatial Headphone Sound																															
Dual Balance On	Dual Balance Reset	Off	On	Small	Medium	Large	Off	On	Off	Light	Normal	Heavy	Off	-	+	Clean	Strong	Dark	Rich	Classical	Off	Forward	Normal	Wide																											
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8
Sound Select																Reverb			Virtual Technician												Phones Type																				
Concert Grand																Room			Off												Normal																				
Studio Grand																Lounge			Noisless												Open																				
Mellow Grand																Small Hall			Deep Resonance												Semi Open																				
Modern Piano																Concert Hall			Light Resonance												Closed																				
Classic E.Piano																Live Hall			Soft												Inner-rear																				
Modern E.Piano																Cathedral			Brilliant												Canal																				
Jazz Organ																																																			
Church Organ																																																			
Harpischord																																																			
Vibraphone																																																			
String Ensemble																																																			
Slow Strings																																																			
Choir																																																			
New Age Pad																																																			
Atmosphere																																																			

METRONOME

METRO-NOME



Time Signature						Metronome Volume																																													
1/4	2/4	3/4	4/4	5/4	3/8	-	+																																												
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8
Tempo + (-2)												Tempo + (+2)																																							
1												2												Metronome Tempo (Musical Term)																											
3												4												Grave..... 40																											
5												6												Largo..... 46																											
7												8												Lento..... 52																											
9												0												Larghetto..... 56																											
																								Adagio..... 60																											
																								Adagietto..... 66																											
																								Andante..... 72																											
																								Andantino..... 80																											
																								Maestoso..... 88																											
																								Moderato..... 96																											
																								Allegretto..... 108																											
																								Animato..... 120																											
																								Allegro..... 132																											
																								Vivace..... 160																											
																								Presto..... 184																											
																								Vivacissimo..... 192																											
																								Prestissimo..... 208																											

CONCERT MAGIC

CONCERT MAGIC



Song Select																																																			
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8
Song Select																																																			
1 Little Star																																																			
2 My Wild Irish Rose																																																			
3 Mary Had A Little Lamb																																																			
4 London Bridge																																																			
5 Fete Jacques																																																			
6 Hark The Herald																																																			
7 Angels Sing																																																			
8 Joy To The World																																																			
9 Deck The Halls																																																			
10 We Wish You A Merry Christmas																																																			
11 Silent Night																																																			
12 O Come All Ye Faithful																																																			
13 Yankee Doodle																																																			
14 Battle Hymn Of The Republic																																																			
15 Clementine																																																			
16 On Susanna																																																			
17 The Campion Faces																																																			
18 The Entertainer																																																			
19 Andante from Symphony No.94 (Haydn)																																																			
20 Chair De Lune																																																			
21 Saxer's Waltz																																																			
22 Gavotte (Gossec)																																																			
23 Bridal Chorus																																																			
24 When Irish Eyes Are Smiling																																																			
25 Wedding March																																																			
26 Santa Lucia																																																			
27 Romance De L'amour																																																			
28 Funerill Funclia																																																			
29 Chapeaux																																																			
30 Pomp And Circumstance																																																			
31 Blue Danube Waltz																																																			
32 Waltz Of The Flowers																																																			
33 Fur Elise																																																			
34 William Tell Overture																																																			
35 When The Saxons Go Marching In																																																			
36 Londonery Air																																																			
37 Auld Lang Syne																																																			
38 Londonderry Air																																																			
39 Old MacDonald Had A Farm																																																			
40 Row Row Row Your Boat																																																			

SETTINGS

Tuning (427 Hz~453 Hz)
440 Hz, -0.5 Hz, +0.5 Hz

Transpose (-6~+5)
Off, On, -, +

Transmit MIDI Program Change
Off, On

MIDI Local Control
Off, On

Multi-timbral Mode
Off, On

Bluetooth
Off, On

MIDI Channel
2, 4, 7, 9, 11, 14, 16

Tuning Value (3 digits)
1 2 3 4 5 6 7 8 9 0

Program Number (3 digits)
1 2 3 4 5 6 7 8 9 0

MIDI Channel
1 3 5 6 8 10 12 13 15

Auto Power Off
Off, 15 min., 60 min., 120 min.

LESSON

Selecting a Lesson book and song

LESSON

Book 1, Book 2, Book 3, Book 4, Book 5

A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2

- + 1 2 3 4 5 6 7 8 9 0

Song Number (3 digits)

Selecting the part to practice

METRO-NOME **SOUND SELECT**
L SETTINGS

L
Press once:
Left-hand only

METRO-NOME **SOUND SELECT**
L SETTINGS

R
Press twice:
Right-hand only

METRO-NOME **SOUND SELECT**
L SETTINGS

L & R
Press 3 times:
Both Left and Right hands

Listening to the song

CONCERT MAGIC **LESSON**
L DEMO

PLAY/STOP **REC**
- RECORDER -

METRO-NOME **SOUND SELECT**
L SETTINGS

RECORDER

Record song

① Enter recording mode

② Select a song memory

③ Start recording

Play song

PLAY/STOP + Song Selection

Erase all songs

① Hold both buttons

② Turn the power on

